ECSE-415 Software for Computer Vision

Introduction to OpenCV-Python




What is OpenCV?




- OpenCV is an open source library for developing computer vision applications
- Cross-platform:
 - C++, C, Python and Java interfaces
 - Supports Windows, Linux, Mac OS, iOS and Android
- Strong focus on real-time applications
 - Multi-core processing
 - Supports hardware acceleration: IPP, OpenCL, CUDA
- Under a BSD license, it can be freely used, distributed and adapted in both academic and commercial apps


Published books about OpenCV

- iOS Application Development with OpenCV 3 (2016)
- OpenCV By Example (2016)
- OpenCV Android Programming By Example (2015)
- OpenCV with Python Blueprints (2015)









Check http://opencv.org/books.html for an up-to-date list of publications

McGill University ECSE-415 Prof. Arbel

OpenCV Interface so far

- OpenCV 1.x
 - First stable release
 - C-based API
- OpenCV 2.x
 - C++ API
- OpenCV 3.x
 - C++ API
 - Java API
 - Python API
- Lots of new methods/fixes are added on each minor release
- The programming interface noticeably changes on each major build

OpenCV Python Interface

- Python is a high level general purpose programming language
 - simplicity and code readability
 - compared to C/C++, Python is slower
- It is possible to create a Python wrapper for a C/C++ code
 - The C/C++ code is running without any performance penalty
 - We can benefit from easy coding in Python
- This is how OpenCV-Python works, it is a Python wrapper around original C++ implementation
- We can also benefit from other highly optimized Python libraries
 - Numpy, SciPy, Matplotlib etc

Installing Python + Packages (Anaconda)

Installing Anaconda (Ubuntu)

- Anaconda is a ready-made Python distributions with more than 100 of popular Python packages
- Download and install Anaconda3
 - We assume the installation directory is ~/anaconda3
 - Allow Anaconda to be added to the system PATH
 - Allow Anaconda to be registered as default Python


Installing Anaconda (Ubuntu)

- Download *Anaconda3-4.4.0-Linux-x86_64.sh* for Python 3.6
- On a Terminal
 - bash Anaconda3-4.4.0-Linux-x86_64.sh
- Follow the prompts on the installer screen
- Accept the defaults
- To make changes take effect, close and then re-open the terminal window

Test Python Installation

- On a Terminal
 - Enter python to run the Python interpreter
 - On the Python terminal, enter import numpy and make sure Numpy is working fine (you will get an error otherwise)


Test Python Installation(Ubuntu)



Jupyter notebook: An Alternative to Python Terminal


- IPython kernel (already installed with Anaconda) provides a rich architecture for interactive Python programming and data visualization
- On a Command Prompt (Windows) or a Terminal (Ubuntu)
 - Enter jupyter notebook
- The Jupyter server will be automatically displayed in a browser tab

Jupyter notebook: An Alternative to Python Terminal




Jupyter notebook: An Alternative to Python Terminal

- Using the New menu, we can create a new Python file
- We can create multiple cells and run each separately
- We can save the notebooks as a .ipynb file



How to Use OpenCV?





McGill University ECSE-415 Prof. Arbel

Setting up OpenCV-Python Ubuntu

Install Dependencies

- Make sure to upgrade and update the pre-installed packages first
 - sudo apt-get upgrade
 - sudo apt-get update
- Install developing tools
 - sudo apt-get install build-essential cmake-gui pkg-config
- Install the following packages for accessing various image formats, video frames and cameras
 - sudo apt-get install libjpeg8-dev libtiff5-dev libjasper-dev libpng12-dev
 - sudo apt-get install libdc1394-22-dev
 - sudo apt-get install libavcodec-dev libavformat-dev libswscale-dev
 - sudo apt-get install libv4l-dev libxvidcore-dev libx264-dev

Install Dependencies

- Install the GTK library, required by the OpenCV highgui module
 - sudo apt-get install libgtk2.0-dev libgtk-3-dev
- Other required libraries
 - sudo apt-get install libtbb2 libtbb-dev libatlas-base-dev gfortran

Building OpenCV on Ubuntu

Check if you are using an up-to-date GCC version (5 or 6)

```
wer@ubuntu:~$ gcc --version
gcc (Ubuntu 5.4.0-6ubuntu1~16.04.4) 5.4.0 20160609
Copyright (C) 2015 Free Software Foundation, Inc.
This is free software; see the source for copying conditions. There is NO
warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

user@ubuntu:~$

■
```

McGill University ECSE-415 Prof. Arbel

Building OpenCV on Ubuntu

- Finally, the easiest way to install OpenCV is using the Anaconda package environment
- In terminal
 - conda update conda
 - conda install opency
- Accept the installation of prerequisite packages
- Wait for installation to complete
- Many other anaconda command can be found at this tutorial

Installing OpenCV on Ubuntu

- The include folder ~/anaconda3/include/opencv & opencv2
 - Contains all the header files required for building application using OpenCV C++
- The lib folder ~/anaconda3/lib
 - Contains all the built library files (.so files)
- The python folder ~/anaconda3/lib/python3.6
 - Contains the built opency-python library

Setting PYTHON_PATH

- We need to inform Python of the location of OpenCV-Python library (cv2.*.so), installed at
 - ~/anaconda3/lib/python3.6/site-packages
- Open .bashrc (gedit ~/.bashrc) and add the following
 - export
 PYTHONPATH=\$PYTHONPATH:~/anaconda3/lib/python3.6/sit
 e-packages
 - Export PATH="~/anaconda3/bin:\$PATH"

Test OpenCV-Python installation

- Open a Terminal
 - Enter python to run the Python interpreter
 - On the Python terminal, enter
 - >import cv2
 - print(cv2.__version__)

```
gary@gary-MacBookPro:~

gary@gary-MacBookPro:~

python 3.6.1 |Anaconda custom (64-bit)| (default, May 11 2017, 13:09:58)

[GCC 4.4.7 20120313 (Red Hat 4.4.7-1)] on linux

Type "help", "copyright", "credits" or "license" for more information.

>>> import cv2

>>> print(cv2.__version__)

3.1.0

>>> I
```

OpenCV Python Interface

Getting Started with Images: Reading images

- Use the function cv2.imread() to read an image
- The function accepts two arguments
 - The first argument is a string containing the path of the image file
 - The optional second argument is a flag
 - cv2.IMREAD_COLOR: Loads a color image (default)
 - cv2.IMREAD_GRAYSCALE: Loads image in grayscale mode
 - You can check the values of these flags by printing them (e.g. print(cv2.IMREAD_COLOR))
- The function returns a Numpy array, containing the image data

Getting Started with Images: Reading images

```
import numpy as np
import cv2

# Load a color image
img = cv2.imread('/home/user/opencv/samples/data/lena.jpg')
```

McGill University ECSE-415 Prof. Arbel

Getting Started with Images: Displaying images

- Use the function cv2.imshow() to display an image
- The function accepts two arguments
 - The first argument is a string indicating the window name
 - The second argument is the image to display

```
import numpy as np
import cv2

# Load a color image
img = cv2.imread('/home/user/opencv/samples/data/lena.jpg')

# Display the image
cv2.imshow('image',img)
# infinitely wait for a user keypress
cv2.waitKey(0)
# Close all windows
cv2.destroyAllWindows()
```

Getting Started with Images: Displaying images

- cv2.waitKey() is a keyboard binding function
- Its argument is the time in milliseconds
- If 0 is passed, it waits indefinitely for a key stroke

```
import numpy as np
import cv2

# Load a color image
img = cv2.imread('C:\opencv\sources\samples\data\lena.jpg')

# Display the image
cv2.imshow('image',img)
# infinitely wait for a user keypress
cv2.waitKey(0)
# Close all windows
cv2.destroyAllWindows()
```

Getting Started with Images: Displaying images


- cv2.destroyAllWindows() simply destroys all the windows we created
- If you want to destroy any specific window, use the function cv2.destroyWindow() where you pass the exact window name as the argument

```
import numpy as np
import cv2

# Load a color image
img = cv2.imread('C:\opencv\sources\samples\data\lena.jpg')

# Display the image
cv2.imshow('image',img)
# infinitely wait for a user keypress
cv2.waitKey(0)

# Close all windows
cv2.destroyAllWindows()
```



3 images